### General

CH4-S3 is a popular small size and cost-effective methane sensor module with excellent performance. Rapid detection of methane gas leaks is possible while maintaining high accuracy over a wide temperature range. In addition, NDIR can be used for more than 10 years in a stable state for a long time.



# ELT Sensor Data Sheet for CH4-S3

### **Features**

- Non-Dispersive Infrared (NDIR) Single Channel
   Technology to measure CH4 levels.
- Excellent compensation of Temperature Effect on CH4 concentration.
- Output : TTL-UART, I2C, ALARM,
   Analog Voltage or PWM is optional.
- Simple Calibration with Non-Periodic Manual

Calibration (0\_MCDL : CAL1) and Periodic Automatic Calibration (0\_ACDL : CAL2).

- Size : 33mmx33mmx13.1mm
- Weight : 10 grams



# **Specifications**

### **Applications**

Gas leakage alarming detector or equipment of CH<sub>4</sub>, LNG or combustible gases in Mine, metallurgy, liquefied gas station, petroleum, fuel gas ,etc.

### **General Performance**

Operating Temperature : -20 ~ 50°C Operating Humidity : 0 ~ 95% RH (Non-condensing), 0 ~ 99% RH (Non-condensing) <sup>(1)</sup> Storage Temperature : -30°C ~70°C

### **Measurement**

Sensing Method : NDIR (Non-dispersive Infrared)
Measurement Range : 0 ~ 100% LEL (=0~50,000ppm vol. is optional) <sup>(2)</sup>
Output Default : % LEL, Optional : ppm
Accuracy : ±3% of F.S.<sup>(3),(4),(5)</sup>
Detection Limit: 2% LEL (=1,000ppm vol.), Resolution: 1% LEL (=500ppm vol.)
Step Response Time (90%, 1/e) : 90 seconds / 45 seconds (Diffusion)
Sampling Interval: 3 seconds

Warming-up Time : < 6 seconds (for Detection), 3 minutes (for Accuracy)

### **Electrical Data**

Power Input :  $5V \pm 5\%$ <sup>(6)</sup>

Current Consumption : Normal mode : 12mA, Peak : 240mA, Sleep < 0.5mA

### **Product Derivatives and Relative Functions**

Products	Feature	Option
CH4-S3	UART,I2C, ALARM, PWM, 0_MCDL(CAL1)/0_ACDL(CAL2)	CH4-S3-3V
CH4-S3L	Sleep mode is added on CH4-S3 for Low Power, which consume < 9mA	CH4-S3L-3V
CH4-S3 <b>G</b>	Resistant up to 99% Humidity for Application of Agricultural Green House	CH4-S3 <b>G</b> -3V
CH4-S3 <b>LG</b>	Sleep mode + 99% Humidity	CH4-S3 <b>LG</b> -3V

<sup>(1)</sup> CH4-S3G : 0 ~ 99% RH (Non-condensing) for Industrial Application of Methane gas.

<sup>(2)</sup> PPM unit output is selectable as option when you designate on issuing order. (500ppm unit)

<sup>(3) 2%</sup> should be added for absolute measurements for uncertainty of calibration gas mixture unless '0' ppm or '0'ppm standard gas calibration is done.

<sup>(4)</sup> Air pressure is assumed as 101.3 kPa.

<sup>(5)</sup> If sensor is affected by the shock, may need field calibration before installation.

<sup>(6)</sup> DC Supply should be regulated without ripple < 100mV, low noise power source is needed for best accuracy.

CH4-S3 has various output TTL-UART, I2C, ALARM while as PWM or Analog voltage is selectable as option. 2.54pitch 13pin side hole connector besides 2mm pitch 10 and 4pin 2 row header connectors.

J-11	Description
1/3	VDD (+5VDC)
2/4	GND

### Pin Map with J11&J12 Connectors

J-12	CH4-S3	CH4-S3 (Analog Voltage Option)						
1	TTL RXD (← CPU of Master Board )							
2	TTL TXD ( $\rightarrow$ CPU	of Master Board)						
3	I2C	SCL						
4	I2C SDA							
5	GND							
6	Reserved Analog Voltage Output (0.5~4.5V)							
7	CAL2-pin : 0_ACDL (for every 7 days ACD	L with periodic CH4-'0'ppm circumstance)						
8	Rese	erved						
9	CAL1-pin : 0_MCDL (for 10 minutes MCDL with CH4-'0'ppm- N2-based-gas or Fresh Air)							
10	Reset (Low Active)							

**UART** 38,400BPS, 8bit, No parity, 1 stop bit 9,600 or 19,200 BPS can selectable through command sets or EK-100SL.

I2C Slave mode only, Internal pull up resister 10kΩ TTL Level Voltage : 0≤V<sub>IL</sub>≤0.8, 2≤V<sub>IH</sub>≤ V<sub>DD</sub>, 0≤V<sub>OL</sub>≤0.4, 2.4≤V<sub>OH</sub>≤ V<sub>DD</sub> (Volt)

ALARM : Open Collector type. ex) Alarm\_On : 25% LEL, Alarm-Off : 20% LEL

Analog Voltage: 0.5~4.5V (option)

#### **PWM** (option)


 $t_{H}$  = 2 msec(Start) + 1,000 msec x (Measurement<sub>(ppm)</sub>/ Range<sub>(ppm)</sub>),  $T_{L}$ = 2,000 ms -  $t_{H}$ ,

J-13	CH4-S3	CH4-S3 (PWM/Analog Voltage Option)					
1	Reserved Analog Voltage Output (0.5~4						
2	Alarm (Ope	en Collector)					
3	G	ND					
4	VDD (·	+5VDC)					
5	TTL TXD ( $\rightarrow$ CPL	J of Master Board )					
6	TTL RXD (← CPU	J of Master Board )					
7	Reserved PWM Output (TTL)						
8	12C	SCL					
9	I2C SDA						
10	Reset (Low Active)						
11	CAL2-pin (for every 7 days ACDL with periodic CH4-'0'ppm circumstance)						
12	Res	Reserved					
13	CAL1-pin (for 10 minutes MCDL with 0	CAL1-pin (for 10 minutes MCDL with CH4-'0'ppm-N2-based-gas or Fresh Air)					

# Pin Map with J13 Connectors


# **Dimensions (unit : mm)**

Dimensions unit : mm




# **0\_MCDL (2 minutes Manual Calibration)**

'0' ppm Manual Calibration can be done by giving start command or low signal to CAL1-pin at least more than 10 minutes since the fresh air is fully balanced near sensor.



# **0\_ACDL (Periodic Automatic Calibration)**

'0' ppm Periodic Automatic Calibration can be used by giving start command or low signal to CAL2-pin. The sensor calibrate automatically first in 2 days, seconds 5 days and every week. '0'ppm Standard Gas can be used when the place doesn't face free air during the period.



- Method 1. UART Command Set; J12: pin-1 (UART-RX) and pin-2 (UART-TX) to Main-Board (J13: pin-5 and pin-6 are available as well.).
- Method 2. I2C Command Set; J12: pin-3 (SCL) and pin-4 (SDA) to Main-Board. (J13: pin-8 and pin-9 are available as well.)
- Method 3. Let Sensor install on Jig Board, **TRB-100ST (Test and Recalibration Board)** with ambient air-flow condition or with 0'ppm Standard Gas and execute by moving jumper following Manual on the website.

Method 4. Send string command set below to RXD-pin of Sensor on Emulation program. **EK-100SL (Evaluation kit, with Emulation program 'ELTWSD')** is available

Method 5	CAL1/	CAL 2-nin	settings for (	ACDI
moundu d.	UNLI/		Soungs for C	_/ODL

CAL1 0_MCDL	CAL 2 0_ ACDL	Function	Process
Low	High	H/W '0'ppm MCDL	Let CH4-S3 sensor be located at ambient place where no methane gas exist and wait 2 minute. '0'ppm Standard gas can be used when '0'ppm is not guaranteed.
High	Low	H/W '0' ppm ACDL	Automatic Calibration can be used where CH4 meet the clear air more than 3 minutes per week.
High	High	Normal	Operate with Factory Calibrated or previously set status

X 1. CAL-1pin and CAL-2pin shouldn't have 'Low' at the same time.

2. Be sure to escape MCDL fetch loop between 2 minutes and 4minutes to avoid inappropriate calibration.

# **Output Descriptions**

### **UART Descriptions**

#### Data Format

SP	SP	SP	D2	D1	'%'	SP	'L'	'E'	'L'	CR	LF
		SP x	3				Sp	ace: (	0x20		
D2 ~ D1						2 b	yte Cl	H4 de	nsity s	string	
	%						0	% : 0x	25		
	SP						Sp	ace: (	0x20		
'LEL'							ίΙ	_EL's	tring		
CR						Carriage return : 0x0D					
LF							Line	feed	: 0x0A	\	

Above 12byte consist by 2 byte hexadecimal digits, <SP>,<SP>, <SP>, D2, D1, 0x25, <SP>, 'L', 'E', 'L', <CR><LF> , where decimal '0' (corresponds to hexadecimal digit '0x30') is replaced by space (corresponds to hexadecimal digit '0x20'),

EX) 7% LEL (= 3,500 ppm) string is '0x20 0x20 0x20 0x20 0x37 0x25 0x20 0x4C 0x45 0x4C, 0x0D 0x0A',, of which display on the screen is '\_\_\_\_7%\_LEL<CR><LF>'.

'ppm' display is Option on sale, which D6~D1 string display the CH4 concentration of

D6	D5	D4	D3	D2	D1	SP	'p'	'p'	'm'	CR	LF
----	----	----	----	----	----	----	-----	-----	-----	----	----

EX) 3,500 ppm string is '0x20 0x20 0x33 0x35 0x30 0x30 0x20 0x70 0x70 0x6D 0x0D 0x0A', of which display on the screen is '\_\_3500\_ppm<CR><LF>'.

### I2C Communication (Only Slave Mode Operation)

Internal pull up resister 10kΩ


Slave Address: 0x31, Slave Address Byte: Slave Address(0x31) 7 Bit + R/W 1 Bit

Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
0	1	1	0	0	0	1	R/W Bit

R/W Bit : Read = 1/Write = 0

When reading the data, Slave Address Byte is 0x63, When writing the data, Slave Address Byte is 0x62.


#### **Block Diagram**



#### **Transmission Sequence in Master**

- 1) I2C Start Condition
- 2) Write Command(Slave Address + R/W Bit(0) = 0x62) Transmission and Check Acknowledge
- 3) Write Command(ASCII 'R' : 0x52) Transmission and Check Acknowledge
- 4) I2C Stop Command
- 5) I2C Start Command
- 6) Read Command(Slave Address + R/W Bit(1) = 0x63) Transmission and Check Acknowledge
- 7) Read 7 Byte Receiving Data from Module and Send Acknowledge

(Delay at least 1ms for reading each byte)




In need of detail protocol specification and time sequence, '**I2C programming guide**' could be provided by contacting Sales Rep.

## **Alarm Descriptions**


Alarm signal operates as Open Collector type and send TTL on signal since CH4 measured value beyond 25% LEL until it go down to 20% LEL. It is designed to be activated when CH4 measured value surpass 25% LEL and deactivated down to 20%LEL to avoid unwanted rapid switching by hysteresis effect.

Alarm\_On : 25% LEL, Alarm-Off : 20% LEL



EK-100SL series is available for customer to enable to change alarm activation & deactivation point. **PWM Descriptions : Option** 

- \* Measurement(ppm) = (tH-2msec)/1000msec x Range(ppm) (tH : High Pulse Width)
- \* Range(ppm) : 0~100% LEL (0~50,000 ppm)




EX) t<sub>H</sub> (High Pulse Width) calculation for 50% LEL in 100% LEL Range. \*Measurement(% LEL) = 50% LEL =  $(t_H-2m_s)/2,000m_{sec} \times Range(% LEL)$ , \*t<sub>H</sub>= 1,000 msec \* (50% LEL / 100% LEL) + 2msec = 502msec (cf:  $T_L$  = Period -  $t_{H=}$  2,000 msec - 502 msec = 1,498 msec.)

### **Analog Voltage Output Descriptions : Option**

Measured Voltage 0.5V~4.5V match proportionally to 0 ~ 100% LEL.

\* CH4 Measurement (ppm) = ((Output voltage- 0.5) / (4.5 - 0.5) voltage) x 100% LEL.



EX) if the Output voltage is 2.5V in 0~100% LEL range,

#### **X** Caution

- 1. The gold cavity part of the sensor module or the PCB outer part should not touch by the customer's case housing. It causes long-term value fluctuation. Be at least 3 mm apart from the housing.
- 2. When removing and inserting the sensor module, do not hold the gold cavity but hold the PCB on both sides. Put on the electret gloves to prevent the static electricity.

(Excessive force on the gold cavity can affect the initial performance and accuracy of the sensor.)

- → If the measured value is wrong, you can calibrate zero point for more than 10 minutes at CAL1 (MCDL) position and use it with high accuracy.
- 3. Do not let water get on, drop, or shock the sensor.
- 4. Do not store the sensors in high temperature and high humidity for long time without applying power. The initial measurement accuracy of the sensor may be affected.
- 5. Be careful not to be affected by static electricity and induction electromagnetic field around sensor. To prevent static electricity from being generated during assembly, wear electrostatic gloves and work on a static-free workbench. (Keep the sensor in the place where the electricity is removed.)
- 6. Install the sensor at a position as far away as possible from the motor or vibration. Vibration or noise may be accuracy affected during sensor operation.
- 7. When using the sensor for the first time or after long term storage, you can use CAL1 MCDL zero point calibration and use it with high accuracy.
- X Specification of C-H Series could be changed without notice.

ELT SENSOR Corp.

Chunui Technopark 101-909) 36, Bucheon-ro 198beon-gil,Wonmi-gu, Bucheon-si, Gyeonggi-do, 420-857,Korea Phone. +82-32-719-8055, <u>http://www.eltsensor.co.kr</u> Subject to change without notice. Printed in KOREA 2018 ELT Sensor Corp. All rights reserved. Nov. 2018.